



®

HO Structure Kit **GRAIN BIN** 933-3123

READ INSTRUCTIONS FIRST BEFORE ASSEMBLY

Check kit for proper number of parts. Trim off flash from parts by cutting or filing. Where walls butt up to one another, make sure to sand edges to insure a right angle joint with no gap between walls. Plastic cement is recommended for the bulk of assembly.

PAINTING

Basic painting can be accomplished with brush, spray can or airbrush. When brushing, use plastic compatible paints to avoid crazing of the plastic. Painting may be done before, during or after assembly.

Glue six pieces (02-11) together to form one band. Glue the first band to the base (01-11) with the short tab down. Then add the next band short tab down with the joint lines staggered with the bands below. Snap the glue tab off of the top course and glue on the roof (01-12). Glue the roof vents (01-15) and the roof cap, either (01-13) for top loading from our GRAIN CONVEYER 933-3124 or (01-14).

DECALING

1. After cutting out the decal, dip in water for 10 seconds, remove and let stand for 1 minute. Slide decal onto surface, position and then blot off any excess water.
2. Lightly brush Micro Sol® on top. This will soften the decal allowing it to conform to irregular surfaces. DO NOT TOUCH DECAL while wet!
3. When the decal is thoroughly dry, check for any trapped air bubbles. Prick them with the point of a small pin or hobby knife blade and apply more Micro Sol®.

